

## XBO 6000 W/HSLA OFR

XBO HSLA for digital cinema projection | Xenon short-arc lamps



### Areas of application

- Cinema projection

### Product family features

- Short arc with highest luminance for brighter screen illumination
- A lifetime of reliable performances with constant 6000 K color temperature
- Easy to maintain
- High level of arc stability
- Hot restart and instant light on screen
- Dimmable in a wide range



Technical data

Electrical data

Nominal current	170 A
Nominal wattage	6000.00 W
Current control range	135...170 A
Nominal voltage	36.0 V

Dimensions & weight



Diameter	78.0 mm
Length	436.0 mm
Length with base excl. base pins/connection	393.00 mm
Light center length (LCL)	171.0 mm <sup>1)</sup>
Cable/wire length, input side	400 mm
Electrode gap cold	7.5 mm
Product weight	1050.00 g
Cable length	400.0

<sup>1)</sup> Distance from end of base to tip of electrode (cold)

Temperatures & operating conditions

Max. permitted ambient temp. pinch point	230 °C
--	--------

Lifespan

Lifespan	650 h
Service Warranty Lifetime	800 h

Additional product data

Base anode (standard designation)	SFaX30-9.5
Base cathode (standard designation)	SFa30-7.9

Capabilities

Burning position	s15/p15 <sup>1)</sup>
Cooling	Forced

<sup>1)</sup> For vertical burning position: anode (+) on top

Environmental information

Information according Art. 33 of EU Regulation (EC) 1907/2006 (REACH)	
Date of Declaration	05-03-2024
Primary Article Identifier	4008321549716   4052899144057   4062172030656
Candidate List Substance 1	Lead
CAS No. of substance 1	7439-92-1
Safe Use Instruction	The identification of the Candidate List substance is sufficient to allow safe use of the article.
Declaration No. in SCIP database	f210b8f7-ea45-4487-a198-f004ed7ee156

# Product datasheet

## Safety advice

Because of their high luminance, UV radiation and internal pressure in both the hot and cold state, XBO lamps may only be operated in enclosed lamp casings specially constructed for the purpose. Xenon lamps are highly explosive. When hot, xenon lamps can cause burn marks. They should only be handled when the lamp is at room temperature. Always use the protective jackets supplied when handling these lamps. When packing the lamps and when installing or removing the lamps without their protective jackets, always wear protective clothing (face shield with neck protector, protective jacket and lint-free, cut-resistant gloves). For more information see the relevant in-pack leaflets and operating instructions.

## Logistical Data

Product code	Product description	Packaging unit (Pieces/Unit)	Dimensions (length x width x height)	Volume	Gross weight
4062172030656	XBO 6000 W/HSLA OFR	Shipping carton box 1	590 mm x 234 mm x 234 mm	32.31 dm <sup>3</sup>	2199.00 g

The mentioned product code describes the smallest quantity unit which can be ordered. One shipping unit can contain one or more single products. When placing an order, for the quantity please enter single or multiples of a shipping unit.

## Disclaimer

Subject to change without notice. Errors and omission excepted. Always make sure to use the most recent release.